


Soil Temp. Moisture EC Sensor

JW-S3S(Z2) RS485 Output



Beijing Jingelway Sci-Tech Co.,Ltd.

AAdd:3-201,Zhenguan International Park,No.7 Jinghai Road,Beijing,102600,China
Tel:86-13520127780 Website:www.jw-iot.com Email:info@jingelway.com

1. Product Introduction

The sensor measures soil moisture content, EC and temperature. It sealed with resin packaged plastic body with sensing rods which can be insert directly into the soil with long time stability. The soil moisture output signal can be RS485, Analog Voltage or Analog Current. It can also be calibrated for specific soils. The sensor is applicable for science research, irrigation, greenhouse, smart agriculture etc.

2. Features

- Integrated with Soil Moisture, EC, Temperature measurement
- Output Interface with RS485 Modbus
- Low salinity sensitivity
- Minimal soil disturbance
- Water proof to IP68 ratings and can be directly buried into soil
- High accuracy with excellent stability
- Reverse power protection and Built-in TVS/ESD protection

3. Technical Parameters

	Range	Accuracy	Resolution
Soil Temperature	-40~80℃	±0.5℃	0.1℃
Soil Moisture	0~100%	2%(0~50%); 3%(50~100%)	0.03%(0~50%); 1%(50~100%)
Soil EC (Conductivity)	0~20000 μ S/cm	±3%(0~10000 μ S/cm); ±5%(10000~20000 μ S/cm)	10 μ S/cm(0~10000 μ S/cm) ; 50 μ S/cm(10000~20000 μ S/cm)
EC Temperature Compensation	0~50℃		
Measurement Technique	Moisture by FDR and EC by AC excitation		
IP Ratings	IP68		
Sensor Rod	Stainless steel		
Sensor Sealed	Epoxy resin		
Installation	Surface or buried installation		
Cable Length	2 meters or Customize		
Power Supply	DC3.6-30V		
Power Consumption	6mA@24V DC		
Output	RS485 Modbus-RTU		

4. Wiring Diagrams

RS485 Modbus

Red (V+): Power Supply +

Black (G): Power Supply -

Yellow (T+): RS485+/A/T+
White (T-): RS485-/B/T-
Green (SET): SETTING mode.


When sensor power-up with the SET wire connected to Power Supply +, then sensor using setting mode communication parameters for RS485. When sensor power-up with the SET wire connected to Power Supply - or unconnected, the sensor using communication parameters in register for RS485. Please refer to the usage below.

ALL RS485 communication parameters (Modbus Slave Address, baud rate, parity, data bits, stop bits) are set in internal register and can be saved when power down, the factory setting is ADDRESS=1, BAUDRATE=9600bps, PARITY=NONE, DATABITS=8bits, STOPBITS=1bit;

Sometimes you may FORGET the communication settings, In this case, you can connect the GREEN & RED wire together to Power Supply+, black wire to Power Supply-, then re-power up the sensor, then the sensor start-up with a fixed communication settings (we call it setting mode) ADDRESS=0, BAUDRATE=9600bps, PARITY=NONE, DATABITS=8bits,

STOPBITS=1bit; Communicate with the sensor using this parameters and then set your desired communication parameters, then disconnect the green wire from Power Supply+, then re-power up the sensor, and the sensor will communicate with your settings.

5. Dimension



6. Safety, Care and Installation

6.1 Safety and Care

- The rods of the Sensor are sharp for ease insertion. Care must be taken and handling precautions followed.
- Avoid touching the rods or exposing them to other sources of static damage, particularly when powered up.
- Do not pull the sensor out of the soil by its cable.
- If you feel any resistance when inserting the sensor into soil, it is likely you have encountered a stone. Stop pushing and re-insert at a new location.

6.2 Installation

Surface installation

- Clear away any stones. Pre-form holes in very hard soils before insertion.
- Push the sensor into the soil until the rods are fully inserted. Ensure good soil contact.
- If you feel strong resistance when inserting the sensor, you have probably hit a stone. Stop, and re-insert at a new location.

Note: The sensor is suitable for soil surface temperature measurements.

Installing at depth

- Make a 45mm diameter hole, preferably at about 10° to the vertical using a auger.
- Push the sensor into the soil until rods are fully inserted. Ensure good soil contact.
- Fill and repack the hole with soil.

Alternatively

- Dig a trench, and install horizontally.

7. Output Signal Conversion

RS485 Modbus-RTU	Temperature: -40~80°C	TEMP=(REGISTER VALUE)/100. When REGISTER VALUE=2013, then TEMP= 2013/100=20.13°C.
	VWC for all ranges	VWC=(REGISTER VALUE)/100. When REGISTER VALUE=2013, then TEMP= 2013/100=20.13%.
	EC for all ranges	EC=(REGISTER VALUE). When REGISTER VALUE=1568, then EC= 1568 μ S/cm.

NOTE: VWC is Volumetric Water Content, EC is Electrical Conductivity.

8. RS485 Modbus Protocol

8.1 Modbus Protocol

Modbus Protocol is widely used to establish master-slave communication between intelligent devices or sensors. A MODBUS message sent from a master to a slave contains the address of the slave, the

function code (e.g. 'read register' or 'write register'), the data, and a check sum (LRC or CRC).

The sensor is RS485 interface with Modbus protocol. The default serial communication settings is slave address 1, modbus rtu, 9600bps, 8 databits and 1 stop bit. All communication settings can be changed with modbus command, and take effective after re-power up the sensor.

Following modbus function code are supported by sensor.

Modbus Function Code 0x03 : used for reading holding register.

Modbus Function Code 0x04 : used for reading input register.

Modbus Function Code 0x06 : used for writing single holding register.

Modbus Function Code 0x10: used for writing multiple holding register.

8.2 Modbus Register

Parameters	Register Addr. (HEX/DEC)	Data Type	Modbus Function Code(DEC)	Range and Comments	Default Value
TEMPRATURE	0x0000 /0	INT16 RO	3/4	-4000-8000 for -40.00~80.00℃.	N/A
VWC-Volumetric Water Content	0x0001 /1	UINT16 RO	3/4	0-10000 for 0-100%	N/A
EC-Electrical Conductivity	0x0002 /2	UINT16 RO	3/4	0-20000 for 0-20000us/cm	N/A
SALINITY	0x0003 /3	UINT16 RO	3/4	0-20000 for 0-20000mg/L	N/A
TDS	0x0004 /4	UINT16 RO	3/4	0-20000 for 0-20000mg/L	N/A
EPSILON	0x0005 /5	UINT16 RO	3/4	88-8188 for 0.88-81.88	N/A
SOILTYPE	0x0020 /32	UINT16 R/W	3/6/16	0-3 0:Mineral 1:Sand 2:Clay 3:Organic	0:Mineral
TEMPUNIT	0x0021 /33	UINT16 R/W	3/6/16	0:℃ 1:℉	0
ECTEMPCOFF	0x0022 /34	UINT16 R/W	3/6/16	0-100 for 0.0%-10.0%	20(2%)
SALINITYCOFF	0x0023 /35	UINT16 R/W	3/6/16	0-100 for 0.00-1.00	55(0.55)
TDSCOFF	0x0024 /36	UINT16 R/W	3/6/16	0-100 for 0.00-1.00	50(0.5)
MEASUREMETHOD	0x0025 /37	UINT16 R/W	3/6/16	0: Continuous Meas. 1: Request Meas.	1
SLAVEADDRESS	0x0200 /512	UINT16 R/W	3/6/16	0-255	1

BAUDRATE	0x0201 /513	UINT16 R/W	3/6/16	0-6 0:1200bps 1:2400bps 2:4800bps 3:9600bps 4:19200bps 5:38400bps	3:9600bps
PROTOCOL	0x0202 /514	UINT16 R/W	3/6/16	0-1 0:Modbus RTU 1:Modbus ASCII	0:Modbus RTU
PARITY	0x0203 /515	UINT16 R/W	3/6/16	0-2 0:None 1:Even 2:Odd	0:None Parity
DATABITS	0x0204 /516	UINT16 R/W	3/6/16	1 1:8 databits	1:8 databits
STOPBITS	0x0205 /517	UINT16 R/W	3/6/16	0-1 0:1 stopbit 1:2 stopbits	0:1 stopbit
RESPONSEDELAY	0x0206 /518	UINT16 R/W	3/6/16	0-255 for 0-2550 milliseconds	0
ACTIVEOUTPUTIN TERVAL	0x0207 /519	UINT16 R/W	3/6/16	0-255 for 0-255 seconds.	0

NOTE:

UINT16:16 bit unsigned integer, INT16:16bit signed integer

RO: Register is Read Only, R/W: Register is Read/Write

HEX is Hexadecimal (data with 0x/0X prefix), DEC is Decimal

8.3 Modbus Register Detail Description

TEMPERATURE		
Data Range	-4000-8000 For -40.00~80.00℃	Default: N/A
Power Down Save	N/A	

NOTE: Temperature value (Binary complement).

Example:When REGISTER = 0x0702 (HEX format), then

VALUE=(0x07*256+0x02)/100=17.94℃.When REGISTER=FF05H (HEX format),then

VALUE=((0xFF*256+0x05)-0xFFFF-0x01)/100 =(0xFF05-0xFFFF-0x01)/100=-2.51℃.

VWC ---Volumetric Water Content		
Data Range	0-10000 For 0-100%	Default: N/A
Power Down Save	N/A	

Note: Volumetric Water Content value.

Example:When REGISTER = 0x0702 (HEX format), then VALUE=(0x07*256+0x02)/100=17.94%

EC ---Electrical Conductivity		
Data Range	0-20000 For 0-20000us/cm	Default: N/A
Power Down Save	N/A	

Note: Electrical Conductivity.

Example:When REGISTER = 0x0702 (HEX format), then VALUE=(0x07*256+0x02)=1794us/cm

SALINITY--- Salinity		
Data Range	0-20000 For 0-20000mg/L	Default: N/A
Power Down Save	N/A	

Note: SALINITY

Example:When REGISTER = 0x0702 (HEX format), then VALUE=(0x07*256+0x02)=1794mg/L,
Salinity is derived by EC, SALINITY=EC* SALINITYCOFF, in which SALINITYCOFF is a coefficient,
please refer to SALINITYCOFF.

TDS---Total Dissolved Solid		
Data Range	0-20000 For 0-20000mg/L	Default: N/A
Power Down Save	N/A	

Note: Total Dissolved Solid

Example:When REGISTER = 0x0702 (HEX format), then VALUE=(0x07*256+0x02)=1794mg/L,
TDS is derived by EC, TDS=EC* TDSCOFF, in which TDSCOFF is a coefficient, please refer to TDSCOFF.

EPSILON--- EPSILON		
Data Range	88-8188 for 0.88-81.88	Default: N/A
Power Down Save	N/A	

Note: Epsilon

Example:When REGISTER = 0x0702 (HEX format), then VALUE=(0x07*256+0x02)/100=17.94,
VWC is derived by EPSILON, VWC is a function of EPSILON. This value is always used for self calibration usage.

TEMPUNIT---Temperature Unit		
Data Range	0:°C 1:°F	Default: 0
Power Down Save	YES	

Note: Temperature Unit.

ECTEMPCOFF---EC Temperature Compensation Coefficient		
Data Range	0-100 for 0.0%-10.0%	Default: 20(2%)
Power Down Save	YES	

Note: EC Temperature Compensation Coefficient

SALINITYCOFF---Salinity Coefficient		
Data Range	0-100 for 0.00-1.00	Default: 55(0.55)
Power Down Save	YES	

Note: Salinity Coefficient.

TDSOFF---TDS Coefficient		
Data Range	0-100 for 0.00-1.00	Default: 50(0.50)
Power Down Save	YES	

Note: TDS Coefficient.

MEASMUREMENTMETHOD---Measure Method		
Data Range	0: Continuous 1: Request	Default: 1
Power Down Save	YES	

Note:In Continuous mode, the sensor always convert the VWC,EC and Temperature and update the internal data and ready for reading. In Request mode, the sensor convert the VWC,EC and Temperature data by receiving the data request command from master device.

SLAVEADDRESS --- Modbus Slave Address		
Data Range	0-255	Default: 1
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

BAUDRATE --- Serial Comm Baudrate		
Data Range	0-5 0:1200bps 1:2400bps 2:4800bps 3:9600bps 4:19200bps 5:38400bps	Default: 3
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

PROTOCOL --- Serial Comm Protocol		
Data Range	0-1 0:Modbus RTU 1:Modbus ASCII	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

PARITY --- Serial Comm Parity		
Data Range	0-2 0:NONE 1:EVEN 2:ODD	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

DATABITS --- Serial Comm Databits		
Data Range	1 1:8 databits	Default: 1
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

STOPBITS --- Serial Comm Stopbits		
Data Range	0-1 0:1 stopbit 1:2 stopbits	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

RESPONSEDELAY --- Serial Comm Response Delay		
Data Range	0-255 for 0-2550 milliseconds, 0 for disabled	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

Note: Sensor will delay a period before response to master request command.

Example: When set to 5 and receive a request from master device, then sensor will delay 5*10ms=50ms, then response to master.

ACTIVEOUTPUTINTERVAL --- Serial Comm Active Output Interval time		
Data Range	0-255 for 0-255 seconds, 0 for disabled	Default: 0
Power Down Save	YES	

Note: Please re-power on the sensor to take effective after set.

Note: Sensor will output the data actively without any master request command.

Note: Only ONE sensor should be on RS485 network, or there will be data collision and corrupt the data on line.

Note: Refer to SETTING mode to exit the Active Output Mode.

Example: When set to 5 then sensor will output the data every 5 seconds without any master request command.

8.4 Modbus Function Code

For description below, data started with 0X/0x means that it's in HEX format.

8.4.1 Function Code 3 Protocol Example

Master Request:AA 03 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x03	1 byte	Function Code 3
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to read
CCCC	2 byte	CRC CHECKSUM

Slave Response:AA 03 MM VV0 VV1 VV2 VV3... CCCC

AA	1 byte	Slave Address,0-255
0x03	1 byte	Function Code 3
MM	1 byte	Register Data Byte Count
VV0,VV1	2 byte	Register Value (High8bits first)
VV2,VV3	2 byte	Register Value (High8bits first)
...	...	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

Example:Read register 0x0200-0x0201,that is slave address and baudrate.

Master Request:01 03 0200 0002 C5B3

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x03
Starting Register Addr.	2 byte	0x0200
Quantity of Register to read	2 byte	0x0002
Checksum	2 byte	0xC5B3

Slave Response:01 03 04 00 01 00 03 EB F2

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x03
Register Data Byte Count	1 byte	0x04
Register Value: Address	2 byte	0x00(HIGH 8 Bits)
		0x01(LOW8 Bits)
Register Value: Baudrate	2 byte	0x00(HIGH 8 Bits)
Checksum	2 byte	0xEBF2

8.4.2 Function Code 4 Protocol Example

Master Request:AA 04 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x04	1 byte	Function Code 4
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to read
CCCC	2 byte	CRC CHECKSUM

Slave Response:AA 04 MM VV0 VV1 VV2 VV3... CCCC

AA	1 byte	Slave Address,0-255
0x04	1 byte	Function Code 4
MM	1 byte	Register Data Byte Count
VV0,VV1	2 byte	Register Value (High8bits first)
VV2,VV3	2 byte	Register Value (High8bits first)

...	...	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

Example:Read register 0x0000-0x0002,that is temperature, soil moisture, and EC.

Master Request:01 04 0000 0003 B00B

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x04
Starting Register Addr.	2 byte	0x0000
Quantity of Register to read	2 byte	0x0003
Checksum	2 byte	0xB00B

Slave Response:01 04 06 08 90 0E 93 02 4E D2 57

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x04
Register Data Byte Count	1 byte	0x06
Register Value: Temperature	2 byte	0x08(HIGH 8 Bits)
		0x90(LOW8 Bits)
Register Value: Soil Moisture	2 byte	0x0E(HIGH 8 Bits)
		0x93(LOW8 Bits)
Register Value: EC	2 byte	0x02(HIGH 8 Bits)
		0x4E(LOW8 Bits)
Checksum	2 byte	0xD257

Temperature =(0x08*256+0x 90)/100=2192/100=21.92 ℃

Soil Moisture =(0x0E*256+0x93)/100=3731/100=37.31%

EC=0x02*256+0x4E=2*256+78 =590 us/cm

8.4.3 Function Code 6 Protocol Example

Master Request:AA 06 RRRR VVVV CCCC

AA	1 byte	Slave Address,0-255
0x06	1 byte	Function Code 6
RRRR	2 byte	Register Addr (High8bits first)
VVVV	2 byte	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

Slave Response:AA 06 RRRR VVVV CCCC

AA	1 byte	Slave Address,0-255
0x06	1 byte	Function Code 6
RRRR	2 byte	Register Addr (High8bits first)
VVVV	2 byte	Register Value (High8bits first)
CCCC	2 byte	CRC CHECKSUM

Example:Write Register 0x0021,that is set temperature unit to ℉.

Request:01 06 0021 0001 1800

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x06
Register Addr.	2 byte	0x0021 (High8bits first)
Register Value	2 byte	0x0001 (High8bits first)
Checksum	2 byte	0x1800

Response:01 06 0021 0001 1800

Slave Addr.	1 byte	0x01
Function Code	1 byte	0x06
Register Addr.	2 byte	0x0021 (High8bits first)
Register Value	2 byte	0x0001 (High8bits first)
Checksum	2 byte	0x1800

8.4.4 Function Code 16 Protocol Example

Master Request:AA 10 RRRR NNNN MM VVVV1 VVVV2 ...CCCC

AA	1 byte	Slave Address,0-255
0x10	1 byte	Function Code 0x10
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to write
MM	1 byte	Register Data Byte Count
VVVV1	2 byte	Register Value(High8bits first)
VVVV2	2 byte	Register Value(High8bits first)
...	...	Register Value(High8bits first)
CCCC	2 byte	CRC CHECKSUM

Slave Response:AA 10 RRRR NNNN CCCC

AA	1 byte	Slave Address,0-255
0x10	1 byte	Function Code 0x10
RRRR	2 byte	Starting Register Addr
NNNN	2 byte	Quantity of Register to write
CCCC	2 byte	CRC CHECKSUM

Example:Write Register 0x0200-0x0201,that is set slave address to 1,and baudrate to 19200bp.

Master Request:01 10 0200 0002 04 0001 0004 BACC


0x01	1 byte	Slave Addr.
0x10(HEX)	1 byte	Function Code 0x10
0x0200	2 byte	Starting Register Addr
0x0002	2 byte	Quantity of Register to write
0x04	1 byte	Register Data Byte Count
0x0001	2 byte	Register Value: Slave Address 1
0x0004	2 byte	Register Value: Baudrate 19200bps
0xBACC	2 byte	CRC CHECKSUM

Salve Response:01 10 0200 0002 4070

0x01	1 byte	Slave Addr.
0x10(HEX)	1 byte	Function Code 0x10
0x0200	2 byte	Starting Register Addr(High8bits first)
0x0002	2 byte	Quantity of Register to write(High8bits first)
0x4070	2 byte	CRC CHECKSUM

9. Software Configuration Utility


9.1 Hardware Setup



9.2 Universal Modbus Comm Utility

You can use software listed below to try reading/writing the register of sensor,

<https://github.com/ed-chemnitz/qmodbus/releases>



9.3 SensorOneSet Configuration Utility

SensorOneSet is a configuration utility to read/set sensor config for all of our serial communication sensor products. Please contact us if you need the English version.

Appendix

Copyright and Trademark

This document is copyrighted, 2019, by Beijing Jingelway Sci-Tech Co.,Ltd. All rights are reserved. Beijing Jingelway Sci-Tech Co.,Ltd. reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission. Information provided in this manual is intended to be accurate and reliable. However, Beijing Jingelway Sci-Tech Co.,Ltd. assumes no responsibility for its use, nor for any infringements upon the rights of third parties, which may result from its use.